CECO Mefiag

A Division of CECO Environmental

BULLETIN 901 SETHCO DEPTH FILTER TUBES

FOR FILTRATION DOWN TO .5 MICRONS



TYPES OF FILTER TUBES AND SUPPORTING CORES

Cotton, polypropylene, and acetate filter tubes are available. Supporting perforated cores for cotton or polypropylene are stainless steel, polypropylene or steel. Supporting cores for acetate tubes are tin plated copper with voile liner.

Stainless steel cores are recommended for mildly acid and all alkaline solutions, pH 4 to 14.

Polypropylene cores are used where all metal contact must be eliminated or where stainless steel is attacked, such as high chloride and sulfuric acid solutions. It is recommended for all acid and alkaline solutions, pH 0-14.

Steel cores are used for dilute alkaline solution, solvents, lacquers, oils, emulsions, etc.

FILTER TUBE SELECTION

See Filter Tube Selection Guide

Cotton filter tubes are recommended for moderately acid and alkaline solutions in the pH range of 3-11.

Polypropylene filter tubes are recommended for concentrated acid and alkaline solutions and for all fluoborate solutions over the entire pH range of 0-14.

Polypropylene filter tubes are also recommended for electro-polishing solutions, as well as certain other highly corrosive solutions.

Acetate filter tubes are recommended for water.

Sethco filter tubes are available in densities to filter out particles from 0.50 to 150 microns. Standard densities are coarse 50 microns, medium 25 microns, fine 15 microns, x-fine 10 microns, x-x-fine 5 microns and Special B 1-3 microns. Most applications use fine density tubes.

Filter tubes are available in a variety of positively controlled densities between .5 and 150 microns to provide the exact degree of micro-clarification your application requires.

PRESERVING THE LIFE OF FILTER TUBES

When Filtering Highly Contaminated Solutions

- 1. Allow sediment to settle overnight and filter from the top of the solution by gradually lowering the intake hose.
- 2. When this procedure is not feasible, use Sethco coarse or medium density filter tubes for the initial filtration. For subsequent filtration use finer filter tubes.
- 3. For maximum filter tube life and efficiency, operate at rated flow rates. Filtering above rated capacity will force solids through the filter tubes or cause permature

For any application not listed in the adjoining columns please feel free to call or write our engineers who will be glad to make appropriate filter tube recommendation.

SETHOO FILTER TUBE SELECTION GUIDE

	ELECTROPLATING SOLUTIONS	FILTER TUBE MATERIAL/CORE	RECOMM'E MICRON RATING
ACID TYPE	Copper, Iron, Led, Tin	Polypropylene/PP	15
(FLUOBORATES) ACID TYPE (NOT FLUOBORATES)	Copper, Tin and Zinc- Less than 6 oz/gal sulfuric	Polypropylene or Cotton/PP	15
	Copper, Tin and Zinc- Over 6 oz/gal sulfuric acid	Polypropylene/PP	15
	Chromium	Polypropylene/PP	3-15
	Gold, Indium, Rhodium, Palladium	Polypropylene/PP	3-10
	Iron Chloride (190°F)	Polypropylene/PP	15
	Nickel (Woods) Nickel (Watts type & Bright)	Polypropylene/PP Polypropylene/PP or Cotton/PP	15 15
	Nickel (Hi-chloride)	Polypropylene/PP or Cotton/PP	15
	Nickel Sulfamate Electrolytic Copper and Nickel	Polypropylene/PP or Cotton/PP	15 10-15
ALKALINE TYPE	Tin (stannate)	Cotton/SS	15-25
ALKALINE CYANIDE TYPE	Brass*, Cadmium*,	Cotton/SS, Polypropylene/PP	15-50
	Copper*, Zinc* Gold, Indium,	Cotton/SS or	3-10
DYDODUOODUATE	Platinum, Silver	Polypropylene/PP	
PYROPHOSPHATE TYPE	Copper, Iron, Tin, etc.	Cotton/SS or Cotton/PP	15-25
ELECTROLESS TYPE	Nickel Plating, Solutions	Polypropylene/PP Cotton/SS or Cotton/PP	3-10
	Copper	Polypropylene/PP	3-10
	CHEMICALS	FILTER TUBE Material/Core	
ACIDS	Acetic-Dilute	Cotton/SS or Polypropylene/PP	
	Acetic-Concentrated Boric Acid	Polypropylene/PP Cotton/SS or Polypropylene/PP	
	Chromic Acid, Hydrochloric, Nitric Phosphoric, and Sulfuric	Polypropylene/PP	
	Hydrofluoric, Fluoboric Acids	Polypropylene/PP	
ALKALIES	Sodium or Potassium Hydroxide	Polypropylene/PP	
	Ammonium Hydroxide- Dilute	Cotton/SS or Polypropylene/PP	
	Ammonium Hydroxide- Concentrated	Polypropylene/PP	
CHEMICALS, MISC.	Biological Solutions	Cotton/SS, Polypropylene/PP	as
	Electropolishing solutions	Polypropylene/PP	chemical supplier or your process dictates
	Pharmaceutical solutions	Cotton/SS, Polypropylene/PP	
	Photographic solutions	Cotton/SS or Polypropylene/PP	
	Radioactive solutions	Cotton/SS	
	Ultrasonic cleaning	Cotton Special B/SS	
	Solutions Nickel Acetate 190° F	Cotton/SS	
	Food Products	Cotton/SS or Polypropylene/PP	
ORGANIC LIQUIDS	Carbon Tetrachloride	Cotton/Steel or SS	
	Dichlorethylene	Cotton/Steel or SS	
	Hydraulic Fluids Lacquers	Cotton/Steel or SS Cotton/Steel or SS	
	Perchlorethylene or	Cotton/Steel or SS	
	Trichlorethylene Solvents	Cotton/Steel or SS	
PETROLEUM PRODUCTS	Fuel Oil, Diesel, Kerosene, Gasoline, Lube Oil	Cotton/Steel or SS	

When operated as hi-speed baths at high temperatures (above 140 °F) or with high alkali content, use Polypropylene/PP

CECOMefiag

A Division of CECO Environmental

700 Emlen Way • Telford, PA 18969

Phone: 215.723.8155

Email: infofhs@onececo.com

www.cecoenviro.com